



CONFIGURATION AND KIT LIST : ARCS II CONSTANT CURVATURE WST LINE SOURCE



**CONFIGURATION AND KIT LIST**  
**ARCS II CONSTANT CURVATURE WST® LINE SOURCE**

Date : 12/2012



CONFIGURATION AND KIT LIST : ARCS II CONSTANT CURVATURE WST LINE SOURCE


ARCS II KIT LIST

CONFIGURATION

ARCS II/SUB SYSTEM	DESCRIPTION	6 ARCS II FOH	8 ARCS II FOH
LA8	Amplified controller 4 x 1800 W/4 Ohms. ethernet network. AES/EBU	2	4
ARCS II	2-way active Constant Curvature WST® enclosure (with 2 coupling bars)	6	8
ARCPLA	Removable front dolly on wheels for ARCS enclosure	6	8
ARCS IICOV	Protective cover for ARCS enclosure	6	8
DO10	Speaker cable: 8 x 4mm <sup>2</sup> CA-COM 10m length	2	4
DO3WFILL	Speaker cable breakout CA-COM > 2 NL-2 + 1 NL4 3m length	2	0
DOFILL-LA8	Speaker cable extension for active 2 way enclosures CA-COM > 2 x NL-4	0	2
DOSUB-LA8	Speaker cable breakout for passive enclosures: CA-COM > 4 x NL-2	0	2
CC4FP	Speakon > Speakon adaptor	2	0
SP.7	Speaker cable: 4 x 4mm <sup>2</sup> NL4 0.7m length	4	4
SP25	Speaker cable: 4 x 4mm <sup>2</sup> NL4 25m length	2	0
ARCBUMP	Rigging element to rig ARCS vertically	2	2
BUMP3	Rigging element for installing ARCS horizontally	4	4
LIFTBAR	Rigging bar for 2 x BUMP3 provided with 3 shackles	2	2
<b>SB28 SYSTEM</b>			
SB28	High power subwoofer: 2 x 18"	4	4
SB28PLA	Removable front dolly for SB28 enclosure	4	4
SB28COV	Protective cover for SB28 enclosure	4	4
<b>SERVICE STARTER KIT ARCS</b>			
KR HSBC34	Diaphragm for HP BC34II (3" driver - 8 ohms)		
KR HPBC34II	HP BC34II (equipped 3" driver - 8 ohms)		
KR HPPH154	HP PH154 (15" speaker - 8 ohms)		
KR EL60	Kit 10 keeper rings 6mm with sling for dollies		
<b>SERVICE STARTER KIT SB28</b>			
KR HPBM18I	Kit HP BM18I Speaker 18"		
KR CAPLATPIN	Kit 10 pins for dolly boards		



6 ARCS II FOH





8 ARCS II FOH

